



1970-72 Chevelle & El Camino (non SS)
Instrument Panel & Cluster Wiring Diagram