

1967-69 CAMARO - FUSE DATA

Circuit	Location	Amp
Stop & Tail Lights	
Side Marker Lights	
Clock	
Cigar Lighter	
Courtesy & Dome Lights	
Trunk Light	
Hazard Flasher	
Dash Gauges & Tell-Tale	
Radio	
Power Windows	
Instrument Panel	
Heater & Air Cond. Motor	
Four Season Air Cond.	
Universal Air Cond.	
Confortron Air Cond.	
Back-Up Lights—		
1967	
1968-69	
Wiper & Washer Motor—		
1967	
1968-69	

Fuse Block 20

Fuse Block 10

Fuse Block 4

Fuse Block 25

In Line 30

In Line 20

In Line 30

Fuse Block 10

Fuse Block 20

Fuse Block 20

Fuse Block 25

NOTE: Flasher located under dash to the right of the steering column.