



*** Fan Speed Selector Switch**

Switch lever position	Contacts made	Fan speed	Resistance in series with Bio Motor
Off	B to None	Low	R ₁
Low	B to L	Low	R ₁
Med	B to L & M	Med	(R ₁ R ₂)/(R ₁ +R ₂)
High	B to L & H	High	None

*Blower switch contacts must be closed before fan switch will be operable.

Temp Control Lever Position	Blower (Master) switch contacts	Vac switch connects vac source to hose #	Compressor switch contacts:	Blower intake air.
OFF	Open	#2 & #3	Open	---
VENT	Closed	#2	Open	Outside car air intake used
COLD (I.A.)	Closed	#3	Closed	Inside car air recirculated
COLD (O.A.)	Closed	None	Closed	Outside car air intake used
HOT	Closed	#2	Open	Outside car air intake used

67 CAMARO .. FACTORY A/C & HEATING CIRCUIT